


Left Hand Buffer Solenoid Assembly

	NUMBER	DESCRIPTION
1	01-080	PIN, COTTER, 1/16 X 1/2 LG
2	01-495	PIN, CLEVIS, 3/16 X 1-1/4 LG
3	294-002-032 294-002-275	SOLENOID, 110V, 60HZ, RIGHT HAND SOLENOID, 220V, 50HZ, RIGHT HAND
4	294-116-074	BUFFER ROD, LEFT HAND
5	294-116-075	BUFFER LINKAGE, LEFT HAND (INC. 4, 7, & 8)
6	294-116-078	BUFFER SOLENOID BRACKET ASM
7	706-903-000	ROD END CLEVIS
8	835-550-002	NUT, JAM, 1/4-28
9	844-049-002	NUT, STOVER LOCK, 1/4-20
10	945-548-000	WASHER, FLAT, 1/4



Right Hand Buffer Solenoid Assembly

	NUMBER	DESCRIPTION
1	01-080	PIN, COTTER, 1/16 X 1/2 LG
2	01-495	PIN, CLEVIS, 3/16 X 1-1/4 LG
3	294-002-033 294-002-274	SOLENOID, 110V, 60HZ, LEFT HAND SOLENOID, 220V, 50HZ, LEFT HAND
4	294-116-072	BUFFER ROD, RIGHT HAND
5	294-116-073	BUFFER LINKAGE, RIGHT HAND (INC. 4, 7, & 8)
6	294-116-078	BUFFER SOLENOID BRACKET ASM
7	706-903-000	ROD END CLEVIS
8	835-550-002	NUT, JAM, 1/4-28
9	844-049-002	NUT, STOVER LOCK, 1/4-20
10	945-548-000	WASHER, FLAT, 1/4

