


BELT TENSIONER ASSEMBLY 070-011-132



ITEM	PART NUMBER	DESCRIPTION
1	000 021 423	Collar
2	807 357 040	Soc. Set Screw Knurled Cup Pt. $\frac{5}{16}$ -18 x $\frac{1}{4}$
3	000 026 031	Spring
4	000 029 605	Shaft
5	000 029 606	Shaft
6	000 029 659	Hanger Arm Assembly
7	000 029 625	Hanger Arm
8	900 110 081	Bearing-Sleeve
9	070 011 106	Spring Extension
10	070 011 109	Spring Clip
11	070 011 131	Pulley-Weldment
12	070 011 133	Shaft
13	070 011 148	V-Belt (Gates #1400 40"/1016 MM)
14	701 320 045	Thrust Washer
15	807 257 060	Set Screw-Socket Cup Pt. $\frac{5}{16}$ -18 x $\frac{3}{8}$
16	900 210 101	Flange Bearing
17	919 005 600	Tru-Arc Ring 5100-62