

# TABLE & BRACKET ASSEMBLY




TABLE & BRACKET ASY



## TABLE & BRACKET ASSEMBLY

ITEM	QTY	PART #	DESCRIPTION	ITEM	QTY	PART #	DESCRIPTION
1	2	090-005-505	FRONT TABLE BRACKET				
2	1	090-005-613	ROD ASSEMBLY, LONG				
3	19	844-057-002	NUT, STOVER LOCK, 5/16 - 18				
4	1	090-005-637	PIVOT SUPPORT BRACKET				
5	2	808-557-140	SCREW, BUTTON HEAD CAP, 5/16 - 18 X 7/8				
6	2	835-549-002	NUT, HEX JAM, 1/4 - 20				
7	1	808-549-200	SCREW, BUTTON HEAD CAP, 1/4 - 20 X 1 1/4				
8	17	808-557-120	SCREW, BUTTON HEAD CAP, 5/16 - 18 X 3/4				
9	1	088-005-501	SPOT TIE ROD ASSEMBLY				
10	1	090-005-615	ROD ASSEMBLY, SHORT				
11	1	088-005-500	RESPOT TIE ROD ASSEMBLY				
12	4	809-849-165	SCREW, HEX, 1/4 - 20 X 1				
13	2	844-069-002	NUT, STOVER LOCK, 7/16 - 14				
14	2	809-869-285	SCREW, HEX, 7/16 - 14 X 1-1/2				
15	9	808-549-120	SCREW, BUTTON HEAD CAP, 1/4 - 20 X 3/4				
16	1	090-005-656	REAR BRACKET SHIM				
17	13	844-049-002	NUT, STOVER LOCK, 1/4 - 20				
18	1	090-005-536	REAR MOUNTING BRACKET				