

**Counter Wheel Assembly – 294-012-151**

	NUMBER	DESCRIPTION
1	294-012-152	Counter Wheel Base
2	294-012-155	Counter Wheel Base Shaft
3	294-012-153	Counter Wheel Arm
4	294-012-119	Drive Shaft Bearing
5	294-012-154	Counter Wheel
6	294-012-156	Counter Wheel Shaft
7	808-549-102	Screw, Button Head, ¼-20 x 5/8, Black
8	01-054	Washer, ¼, Split
9	01-056	Washer, ¼, Flat
10	294-115-612	Counter Wheel, 20-Tooth
11	294-115-046	Encoder
12	817-921-060	Screw, Pan Head, 4-40 x 3/8, SEMS
13	01-007	Set Screw, 8-32 x 1/4

