



Express Control Box Fuses



115 Volt Fuses

| | NUMBER | DESCRIPTION |
|------------------------------|-------------|-------------|
| F1 Cleaner Pump | 294-115-366 | 2A Fuse |
| F2 Oil Transfer Roller Motor | 294-115-166 | 4A Fuse |
| F3 Vacuum Motor | 294-115-373 | 10A Fuse |
| F4 Drive Motor | 294-115-374 | 6.25A Fuse |
| F5 Buffer Solenoids | 294-115-375 | 8A Fuse |
| F6 Vac Head Solenoids | 294-115-375 | 8A Fuse |

230 Volt Fuses

| | NUMBER | DESCRIPTION |
|------------------------------|-------------|-------------|
| F1 Cleaner Pump | 294-115-365 | 1A Fuse |
| F2 Oil Transfer Roller Motor | 294-115-366 | 2A Fuse |
| F3 Vacuum Motor | 294-115-367 | 5A Fuse |
| F4 Drive Motor | 294-115-166 | 4A Fuse |
| F5 Buffer Solenoids | 294-115-166 | 4A Fuse |
| F6 Vac Head Solenoids | 294-115-166 | 4A Fuse |