


**294-002-421, DASH ASSEMBLY – 220 VOLT**  
**294-002-490, DASH ASSEMBLY – 110 VOLT**



**294-002-421, DASH ASSEMBLY – 220 VOLT**  
**294-002-490, DASH ASSEMBLY – 110 VOLT**

	<b>PART NO.</b>	<b>DESCRIPTION</b>	<b>QTY</b>
1	294-002-440	DASH PLATE	1
2	294-002-215	DASH CONNECTOR SUPPORT	1
3	294-002-218	PANEL MOUNT POWER INLET	1
4	294-002-279	MANUAL REVERSE SWITCH ASSEMBLY (See Item 17)	1
5	294-002-508	USB PROGRAMMING CABLE, DASH TO CONTROL BOX	1
6A	294-002-323	CIRCUIT BREAKER, 30A	1
6B	294-002-214	CIRCUIT BREAKER, 14A	1
7	294-002-185	LABEL, COM-PORT SYMBOL	1
8	294-002-183	LABEL, MANUAL REVERSE SYMBOL	1
9	02-013	WIRE CLAMP, PLASTIC	2
10	01-178	SCREW, 4-40 X 3/8 FLAT HEAD	2
11	01-618	LOCK WASHER, #4 EXTERNAL TOOTH COUNTERSUNK	2
12	01-033	LOCK WASHER, #10 EXTERNAL TOOTH	7
13	01-021	SCREW, 10-32 X 1/2 PAN HEAD	7
14	01-010	SCREW, 8-32 X 1/2 PAN HEAD	2
15	01-016	LOCK WASHER, #8 EXTERNAL TOOTH	2
16	01-015	NUT, HEX, 8-32	2
17	294-002-213	MANUAL REVERSE SWITCH (SWITCH ONLY)	1